

McCallum Made Chicken Tractors

Side Wheels and Trolley Assembly

I am assuming that you have successfully assembled the chicken tractor and you just have to get the wheels attached and the trolley assembled.

1. Before attaching the side lever arms to the chicken tractor, fit a wheel to each axle (with a washer on either side), and then the nyloc nut. They should look like this, and the wheel should NOT be rubbing against the lever arm.



2. Now, place the side wheels on either side of your chicken tractor, directly below the handles holding the stainless steel ring, through the 12.7mm hole. Tighten the nyloc nuts from the inside of the chicken tractor. The nuts should be tightened quite firmly, but not so tight that the wheeled legs cannot rotate.

3. To assemble the **trolley jack**, place wheels on axles, and tighten the nyloc nut. Bolt the towing arm to the towing handle through holes provided. The trolley jack is now complete.

4. To prepare the chicken tractor for movement, lift the chicken tractor by rotating the side arms and slipping the stainless steel ring over the arm to hold it in place. Attach the trolley to the towing lug and move your chicken tractor where ever you wish.

